




**AIRPLANE FLIGHT MANUAL
FOR THE POWERED SAILPLANE
HK 36 TTC**

Engine : Rotax 914 F3 or 914 F4
Model : HK 36 TTC
Serial No. : 36655
TC Data Sheet No. : SF 3/82
Doc. No. : 3.01.20-E
Date of Issue : 03 Mar 1997

Pages identified by "ACG-appr." in the List of Effective Pages are approved

Signature
Authority

Winkler 

AUSTRO CONTROL GmbH
Abteilung Flugtechnik
Außenstelle Ost
A-1300 Wien-Flughafen, Hangar 2

Stamp

Original date of

15. April 1997

This Powered Sailplane must be operated in compliance with the instructions contained herein.

Prior to operation of this Powered Sailplane, the Pilot must take note of the provisions of the flight manual.

This powered sailplane is approved for U.S. registration under the provisions of FAR 21.29, and is required by FAA No. G51EU.

DIAMOND AIRCRAFT
N.A. OTTO-STR. 5
A-2700 WIENER NEUBAU
AUSTRIA



PREFACE

Congratulations on your choice of the HK 36 TTC Powered Sailplane. Skilful operation of an airplane will ensure your safety and provide you with hours of enjoyment. Therefore, you should take the time to get familiar with your new HK 36 TTC.

We ask you to read this manual thoroughly and to pay attention to the recommendations given in it, so that you can expect many hours of incident-free flight operation from your Powered Sailplane.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				0 - 1






0.1 RECORD OF REVISIONS

Any revision of the present manual, except current weighing data, must be recorded in the following table and, in the case of approved sections, endorsed by the responsible airworthiness authority.

The new or amended text on the revised page will be indicated by a black vertical line in the left hand margin, and the Revision No. and the date will be shown on the bottom of the page.

If you have purchased a second hand HK 36 TTC, please let us know your address so that we can supply you with the publications you need for the safe operation of the Powered Sailplane.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				0 - 2

Rev. No.	Sec.	Pages	Date of Revision	Approval	Date of Approval	Date Inserted	Signature
1	0	0-0, 0-3 through 0-6	25 Aug 1997	  	04. Sep. 1997		
	2	2-17					
	3	3-2					
	4	4-3, 4-4, 4-25					
	5	5-3, 5-6					
	7	7-13					
2	0	0-3, 0-4	28 Oct 1998	 	29. Okt. 1998		
	2	2-10					

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997	2	28 Oct 1998		0 - 3

0.2 LIST OF EFFECTIVE PAGES

Section	Page No.	Date	Section	Page No.	Date
0	0 - 0	25 Aug 1997	2	ACG-Appr. 2 - 10	28 Oct 1998
	0 - 1	03 Mar 1997		ACG-appr. 2 - 11	03 Mar 1997
	0 - 2	03 Mar 1997		ACG-appr. 2 - 12	03 Mar 1997
	0 - 3	28 Oct 1998		ACG-appr. 2 - 13	03 Mar 1997
	0 - 4	28 Oct 1998		ACG-appr. 2 - 14	03 Mar 1997
	0 - 5	25 Aug 1997		ACG-appr. 2 - 15	03 Mar 1997
	0 - 6	25 Aug 1997		ACG-appr. 2 - 16	03 Mar 1997
	0 - 7	03 Mar 1997		ACG-appr. 2 - 17	25 Aug 1997
1	1 - 1	03 Mar 1997	3	3 - 1	03 Mar 1997
	1 - 2	03 Mar 1997		ACG-appr. 3 - 2	25 Aug 1997
	1 - 3	03 Mar 1997		ACG-appr. 3 - 3	03 Mar 1997
	1 - 4	03 Mar 1997		ACG-appr. 3 - 4	03 Mar 1997
	1 - 5	03 Mar 1997		ACG-appr. 3 - 5	03 Mar 1997
	1 - 6	03 Mar 1997		ACG-appr. 3 - 6	03 Mar 1997
	1 - 7	03 Mar 1997		ACG-appr. 3 - 7	03 Mar 1997
	1 - 8	03 Mar 1997		ACG-appr. 3 - 8	03 Mar 1997
2	2 - 1	03 Mar 1997		ACG-appr. 3 - 9	03 Mar 1997
	ACG-appr. 2 - 2	03 Mar 1997		ACG-appr. 3 - 10	03 Mar 1997
	ACG-appr. 2 - 3	03 Mar 1997		ACG-appr. 3 - 11	03 Mar 1997
	ACG-appr. 2 - 4	03 Mar 1997		ACG-appr. 3 - 12	03 Mar 1997
	ACG-appr. 2 - 5	03 Mar 1997		ACG-appr. 3 - 13	03 Mar 1997
	ACG-appr. 2 - 6	03 Mar 1997		ACG-appr. 3 - 14	03 Mar 1997
	ACG-appr. 2 - 7	03 Mar 1997		ACG-appr. 3 - 15	03 Mar 1997
	ACG-appr. 2 - 8	03 Mar 1997		ACG-appr. 3 - 16	03 Mar 1997
	ACG-appr. 2 - 9	03 Mar 1997		ACG-appr. 3 - 17	03 Mar 1997

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997	2	28 Oct 1998		0 - 4

Section	Page No.	Date	Section	Page No.	Date
4	4 - 1	03 Mar 1997	5	5 - 1	03 Mar 1997
	ACG-Appr. 4 - 2	03 Mar 1997		ACG-Appr. 5 - 2	03 Mar 1997
	ACG-Appr. 4 - 3	25 Aug 1997		ACG-Appr. 5 - 3	25 Aug 1997
	ACG-Appr. 4 - 4	25 Aug 1997		ACG-Appr. 5 - 4	03 Mar 1997
	ACG-Appr. 4 - 5	03 Mar 1997		ACG-Appr. 5 - 5	03 Mar 1997
	ACG-Appr. 4 - 6	03 Mar 1997		5 - 6	25 Aug 1997
	ACG-Appr. 4 - 7	03 Mar 1997		5 - 7	03 Mar 1997
	ACG-Appr. 4 - 8	03 Mar 1997		5 - 8	03 Mar 1997
	ACG-Appr. 4 - 9	03 Mar 1997		5 - 9	03 Mar 1997
	ACG-Appr. 4 - 10	03 Mar 1997		5 - 10	03 Mar 1997
	ACG-Appr. 4 - 11	03 Mar 1997	6	6 - 1	03 Mar 1997
	ACG-Appr. 4 - 12	03 Mar 1997		6 - 2	03 Mar 1997
	ACG-Appr. 4 - 13	03 Mar 1997		6 - 3	03 Mar 1997
	ACG-Appr. 4 - 14	03 Mar 1997		6 - 4	03 Mar 1997
	ACG-Appr. 4 - 15	03 Mar 1997		6 - 5	03 Mar 1997
	ACG-Appr. 4 - 16	03 Mar 1997		6 - 6	03 Mar 1997
	ACG-Appr. 4 - 17	03 Mar 1997		6 - 7	03 Mar 1997
	ACG-Appr. 4 - 18	03 Mar 1997		6 - 8	03 Mar 1997
	ACG-Appr. 4 - 19	03 Mar 1997		6 - 9	03 Mar 1997
	ACG-Appr. 4 - 20	03 Mar 1997		6 - 10	03 Mar 1997
	ACG-Appr. 4 - 21	03 Mar 1997		6 - 11	03 Mar 1997
	ACG-Appr. 4 - 22	03 Mar 1997		6 - 12	03 Mar 1997
	ACG-Appr. 4 - 23	03 Mar 1997		ACG-Appr. 6 - 13	03 Mar 1997
	ACG-Appr. 4 - 24	03 Mar 1997			
	ACG-Appr. 4 - 25	25 Aug 1997			
	ACG-Appr. 4 - 26	03 Mar 1997			
	ACG-Appr. 4 - 27	03 Mar 1997			

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997	1	25 Aug 1997		0 - 5


Section	Page No.	Date
7	7 - 1	03 Mar 1997
	7 - 2	03 Mar 1997
	7 - 3	03 Mar 1997
	7 - 4	03 Mar 1997
	7 - 5	03 Mar 1997
	7 - 6	03 Mar 1997
	7 - 7	03 Mar 1997
	7 - 8	03 Mar 1997
	7 - 9	03 Mar 1997
	7 - 10	03 Mar 1997
	7 - 11	03 Mar 1997
	7 - 12	03 Mar 1997
	7 - 13	25 Aug 1997
	7 - 14	03 Mar 1997
	7 - 15	03 Mar 1997
8	8 - 1	03 Mar 1997
	8 - 2	03 Mar 1997
	8 - 3	03 Mar 1997
9	Supplements	03 Mar 1997

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997	1	25 Aug 1997		0 - 6

0.3 TABLE OF CONTENTS

	SECTION
GENERAL	
(a non-approved section)	1
LIMITATIONS	
(an approved section)	2
EMERGENCY PROCEDURES	
(an approved section)	3
NORMAL PROCEDURES	
(an approved section)	4
PERFORMANCE	
(a partly approved section)	5
MASS (WEIGHT) AND BALANCE / EQUIPMENT LIST	
(a non-approved section)	6
POWERED SAILPLANE AND SYSTEMS DESCRIPTION	
(a non-approved section)	7
POWERED SAILPLANE HANDLING, CARE AND MAINTENANCE	
(a non-approved section)	8
SUPPLEMENTS	
(a partly approved section)	9

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				0 - 7



SECTION 1

GENERAL

	Page No.
1.1 INTRODUCTION	1-2
1.2 CERTIFICATION BASIS	1-2
1.3 WARNINGS, CAUTIONS AND NOTES	1-3
1.4 EXPLANATIONS	
1.4.1 Abbreviations	1-4
1.4.2 Physical Units	1-5
1.4.3 Special Terms	1-5
1.5 DESCRIPTIVE DATA	1-6
1.6 THREE-VIEW DRAWINGS	1-7

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				1-1

1.1 INTRODUCTION

The Powered Sailplane Flight Manual has been prepared to provide pilots and instructors with information for the safe and efficient operation of the Powered Sailplane.

This manual includes the material required to be conveyed to the Pilot by JAR-22. It also contains supplementary data supplied by the Powered Sailplane Manufacturer.

This Flight Manual conforms to the actual version of the customer's airplane. However, any optional equipment (COM, NAV, etc.) is not considered. For their operation, the operating manual of the respective manufacturer must be followed.

This manual must always be kept on board the airplane.

1.2 CERTIFICATION BASIS

The HK 36 TTC Powered Sailplane has been type certified by Austro Control GmbH (ACG) in accordance with Change 5 of JAR-22 from 28 Oct 1995 for sailplanes and powered sailplanes as a derivative of the HK 36 TC. The HK 36 TC is a variant of the HK 36 R, which was type certified in accordance with Change 4 from 07 May 1987. The Type Certificate Data Sheet No. SF 3/82 has been extended.

Category of Airworthiness: Utility.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				1 - 2

1.3 WARNINGS, CAUTIONS AND NOTES

The following definitions apply to warnings, cautions and notes used in the Flight Manual.

WARNING

Means that the non-observation of the corresponding procedure leads to an immediate or important degradation of flight safety.

CAUTION

Means that the non-observation of the corresponding procedure leads to a minor or to a more or less long term degradation of flight safety.

NOTE

Draws the attention on any special item not directly related to safety but which is important or unusual.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				1 - 3

1.4 EXPLANATIONS

1.4.1 ABBREVIATIONS

ACG	Austro Control GmbH
AGL	Above Ground Level
CG	Center of Gravity
CFRP	Carbon Fiber Reinforced Plastic
GFRP	Glass Fiber Reinforced Plastic
ISA	International Standard Atmosphere
EGT	Exhaust Gas Temperature
OAT	Outside Air Temperature
IAS	Indicated Airspeed (read from airspeed indicator without any correction of errors).
TAS	True Airspeed (IAS corrected for errors due to instrument, system, altitude and temperature)

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				1 - 4

1.4.2 PHYSICAL UNITS

	SI units	US units	conversions
length	[mm] millimeters [m] meters	[in.] inches [ft.] feet	[mm] / 25.4 = [in.] [m] / 0.3048 = [ft.]
velocity	[km/h] kilometers per hour [m/s] meters per second	[kts.] knots [mph] miles per hour [fpm] feet per minute	[km/h] / 1.852 = [kts.] [km/h] / 1.609 = [mph] [m/s] * 196.85 = [fpm]
rotary speed	[min ⁻¹] revolutions per minute	[RPM] revolutions per minute	[min ⁻¹] = [RPM]
mass	[kg] kilograms	[lbs.] pounds	[kg] * 2.2046 = [lbs.]
force, weight	[N] Newtons	[lbs.] pounds	[N] * 0.2248 = [lbs.]
pressure	[hPa] Hectopascal [mbar] millibar [bar] bar	[inHg] inches mercury column [psi] pounds per square inch	[hPa] = [mbar] [hPa] / 33.86 = [inHg] [bar] * 14.504 = [psi]
current intensity	[A] Amperes		-
capacity	[Ah] Ampere hours		-
voltage	[V] Volts		-

1.4.3 SPECIAL TERMS

Pressure altitude	Altitude indicated by the altimeter when the subscale is adjusted to 1013.25 mbar or 1013.25 hPa (29.92 inHg)
Service ceiling	Maximum altitude that can be reached with a climb rate of at least 0.5 m/s (approximately 100 ft./min.)
Take-off roll	Distance between the start of the take-off run and the lift-off point
Take-off distance	Distance between the start of the take-off run and the point above which the airplane is able to clear a 15 m (approximately 50 ft.) obstacle
Non-lifting parts	Fuselage, rudder, horizontal tail surfaces and useful load
Useful load	Crew, baggage and fuel

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				1 - 5

1.5 DESCRIPTIVE DATA

The HK 36 TTC is a two-seated powered sailplane of fiber-composite construction, designed in compliance with JAR-22; Category of Airworthiness: Utility.


It is a low wing airplane with T-tail, side-by-side seating configuration, tricycle landing gear and Schempp-Hirth type air brakes in the upper surface of the wings.

In order to enable a fast disassembly and space-saving storage, the airplane can be fitted with a wing folding mechanism.

The power plant is a Rotax R 914 F engine with an mt-propeller MTV-21-A-C-F/CF175-05 hydro-mechanically variable pitch propeller.

Span	with winglets	: 16.33 m	53.58 ft.
	without winglets	: 16.01 m	52.53 ft.
Length		: 7.28 m	23.88 ft.
Height		: 1.78 m	70.08 in.
MAC		: 1.004 m	39.53 in.
Wing area		: 15.30 m ²	165.7 sq.ft.
Max. wing loading		: 50.30 kg/m ²	10.30 lbs./sq.ft.
Aspect ratio		: 17.11	
Airfoil		: Wortmann FX 63-137	

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				1 - 6



SECTION 2

LIMITATIONS

	Page No.
2.1 INTRODUCTION	2 - 2
2.2 AIRSPEED	2 - 3
2.3 AIRSPEED INDICATOR MARKINGS	2 - 6
2.4 POWER PLANT, FUEL AND OIL	2 - 7
2.5 POWER PLANT INSTRUMENT MARKINGS	2 - 11
2.6 MASS (WEIGHT)	2 - 12
2.7 CENTER OF GRAVITY	2 - 12
2.8 APPROVED MANEUVERS	2 - 13
2.9 MANEUVERING LOAD FACTORS	2 - 13
2.10 FLIGHT CREW	2 - 13
2.11 KINDS OF OPERATION	2 - 14
2.12 FUEL	2 - 14
2.13 AEROTOW, WINCH AND AUTOTOW LAUNCHING	2 - 15
2.14 OTHER LIMITATIONS	2 - 15
2.15 LIMITATION PLACARDS	2 - 16

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 1

2.1 INTRODUCTION

Section 2 includes operating limitations, instrument markings, and basic placards necessary for safe operation of the Powered Sailplane, its engine, standard systems and standard equipment.

The limitations included in this section and in Section 9 have been approved by Austro Control GmbH (ACG).

WARNING

All operation values must be kept within the limits stated herein during flight.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 2

2.2 AIRSPEED

NOTE

The airspeeds shown below must be understood as IAS.

Airspeed limitations

Airspeed limitations and their operational significance are shown below:

Airspeed	IAS			Remarks
	km/h	kts.	mph	
V _{NE} Never exceed speed	261	141	162	Do not exceed this speed in any operation and do not use more than 1/3 of control deflection. (Do not use more than 1/3 of the travel between position of the controls for unaccelerated flight and deflection to stop.)
V _{RA} Rough air speed	210	113	130	Do not exceed this speed except in smooth air, and then only with caution. Examples of rough air are lee-wave rotors, thunderclouds, etc.
V _A Maneuvering speed	176	95	109	Do not make full or abrupt control movements above this speed, as the Powered Sailplane could become overstressed by full control movement under certain conditions.
V _{ABF} Maximum admissible speed with air brakes fixed in half extended position	150	81	93	Above this speed, the air brakes could become extended inadvertently over the half extended position by aerodynamic forces.

The WARNINGS on the following page must be complied with.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 3

WARNING

In order to ensure the flutter safety of the airplane, the never exceed speed is reduced at pressure altitudes above 2000 meters or 6500 ft. (see Article 4.5.7).

WARNING

At speeds beyond the rough air speed, the airplane may become overstressed by heavy gusts (lee-wave rotors, thunderclouds, whirlwinds and turbulence at close range to mountain ridges).

WARNING

The maneuvering speed stated on the previous page applies to the maximum T/O mass (max. T/O weight) of 770 kg (1698 lbs.)
At lower flight masses, the following limits must be applied:

T/O mass	T/O weight	Maneuvering speed v_A		
		kg	lbs.	km/h
700	1543	168	91	104
650	1433	162	87	101
600	1323	155	84	96

WARNING

These speeds are not marked on the airspeed indicator. Simultaneous full deflection of elevator and rudder can overstress the airplane, even at speeds below v_A .

Diverse airspeeds

Airspeed		IAS			Remarks
		km/h	kts.	mph	
v_y	Best rate of climb speed	110	59	68	This airspeed is marked on the airspeed indicator with a blue line. At this airspeed, the airplane climbs with the maximum possible rate of climb.
v_x	Best angle of climb speed	97	52	60	This airspeed is not marked on the airspeed indicator. At this airspeed, the airplane climbs with the maximum possible angle of climb.
	Recommended lowest airspeed for approach	105	57	65	See NOTE below.

NOTE

Conditions such as strong headwind, danger of wind shear, turbulence, or wet wings require a higher approach speed.

Stalling speeds

see Article 5.2.2

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 5

2.3 AIRSPEED INDICATOR MARKINGS

Airspeed indicator markings and their color-code representation are shown below:

Marking	Value or Range (IAS)			Meaning
	km/h	kts.	mph	
green arc	86 - 210	46 - 113	53 - 130	Normal Operating Range. Lower limit is $1.1 v_{S1}$ at max. flight mass (weight) and most forward CG. Upper limit is v_{RA} .
yellow arc	210 - 261	113 - 141	130 - 162	Caution Range, v_{RA} to v_{NE} . Maneuvers must be conducted with caution and only in smooth air.
red line	261	141	162	Maximum speed for all operations v_{NE} .
blue line	110	59	68	Best rate-of-climb speed v_y .
yellow triangle	105	57	65	Approach speed at max. flight mass (weight).

2.4 POWER PLANT, FUEL AND OIL

Engine manufacturer : Bombardier Rotax
 Engine model : Rotax 914 F3 or 914 F4

NOTE

The engine drives the propeller through a speed-reducing gear with a gear ratio of 2.4286:1. The built-in tachometer indicates the propeller speed. Consequently, all speeds given in this manual are propeller speeds (in contrast to the Operator's Manual for the Engine).

Max. T/O power (5 minutes) : 84.5 kW (115 DIN hp.)
 Max. T/O RPM : 2385 at 38.4 inHg

Max. continuous power : 73.5 kW (100 DIN hp.)
 Max. continuous RPM : 2260 at 34 inHg

Idle RPM : 600
 Power check RPM : 2300 ± 50 at 38.4 inHg

CAUTION

At high ambient temperatures or at high altitudes, the maximum admissible manifold pressure cannot be reached, as the turbo control unit prevents excessive airbox temperatures by decreasing the manifold pressure.

Outside air temperature (OAT) at high altitude		Deviation from International Standard Atmosphere (ISA)		Max. manifold pressure obtainable up to altitude	
[°C]	[°F]	[°C]	[°F]	[m]	[ft.]
-1	30	ISA	ISA	2440	8000
17	63	ISA + 10°	ISA + 18°	1220	4000
35	95	ISA + 20°	ISA + 36°	0	0

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 7

NOTE

During normal operation, take off power should only be selected until a safe altitude is reached. The engine wear is higher compared to maximum continuous power.


Maximum cylinder head temperature	:	<u>135° C (275° F)</u>
Minimum oil temperature	:	<u>50° C (122° F)</u>
Maximum oil temperature	:	<u>130° C (266° F)</u>
Favorable oil temperature	:	<u>approximately 90° - 110° C (194° to 230° F)</u>
Minimum oil pressure	:	<u>1.5 bar (22 psi)</u>
Maximum oil pressure	:	<u>7 bar (102 psi)</u> , only during a short time in case of cold-start
Normal oil pressure	:	<u>1.5 to 5 bar (22 to 73 psi)</u>
Max. oil consumption	:	<u>0.1 liters per hour (approximately 0.1 US quarts per hour)</u>
Oil quantity	minimum	: <u>2.0 liters (2.1 US quarts)</u>
	maximum	: <u>3.0 liters (3.2 US quarts)</u>

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 8

Oil grade : Automotive lubricants with additives for transmission gears with SAE ratings complying with seasonal temperatures (see chart). The lubricant quality rating according to the API system must be "SF" or "SG" + "GL4" or "GL5". Do not use fully synthetic lubricants, in particular when using AVGAS or other leaded fuels. Multi-grade oils are recommended.

CAUTION

Because of the incompatibility with automotive lubricants, Aviation grade oil should not be used under any circumstances!



*outside Air Temp.*Admissible OAT range

For starting engine : -25 to +50 °C (-13 to +122 °F)

For OATs below -25 °C (-13 °F), the engine must be pre-warmed.

Propeller manufacturer : mt-propeller, Straubing, Germany

Propeller model : Hydraulically variable pitch propeller
MTV-21-A-C-F/CF175-05

Low pitch : 16.5° ± 0.2°

Starting pitch : 19° ± 1°

Feathered pitch : 83° ± 1°

Counterweights at low pitch : 32.5° ± 1°

High pitch : 28° ± 1°

| Propeller governor : Woodward A210790 or
| McCauley DCFU290D17B/T2

Pressure accumulator : P-447

*vid +5°C
Under 0°C kuperäzomere mot luftinbeg
for att värma kylsvatten. 20min.
< +5°C Längre tid.*

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997	2	28 Oct 1998		2 - 10

2.5 POWER PLANT INSTRUMENT MARKINGS

Power plant instrument markings and their color code representation are shown below:

Indicator	Red Line	Green Arc	Yellow Arc	Red Line
	Minimum Limit	Normal Operating Range	Caution Range	Maximum Limit
RPM indicator	-	600 - 2260 RPM	2260 - 2385 RPM	2385 RPM
Oil temperature indicator	50° C	50° - 130° C	-	130° C
Cylinder head temperature indicator	-	-	-	135° C
Oil pressure indicator	<i>0.8 bar</i> 4.5 bar	<i>2.0</i> 1.5 - 5 bar	<i>0.8 - 2.0 bar</i> 5 - 7 bar	7 bar
Manifold pressure indicator	-	-	34 - 38.4 inHg	38.4 inHg
Fuel quantity indicator	-	-	-	-

K
K
X

K

The following table shows the representation of the warning and caution lights:

Light	red	amber
Manifold pressure	<i>continuous: manifold pressure exceeds 1500 hPa (44.3 inHg)</i> <i>flashing: T/O power selected for more than 5 minutes</i>	-
Turbo	-	<i>flashing: sensor defective</i>
Fuel pressure	fuel pressure less than 0.15 bar above airbox pressure	-
Generator	<i>voltage exceeds 16.2 V or generator failure (low fuel)</i>	-
Temperature	-	EGT exceeds 950° C (1740° F) or airbox temp. exceeds 72° C (162° F)

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 11

2.6 MASS (WEIGHT)

Maximum take-off mass (max. T/O weight)	: <u>770 kg</u>	(1698 lbs.)
Maximum landing mass	: <u>770 kg</u>	(1698 lbs.)
Maximum mass of all non-lifting parts	: 610 kg	(1345 lbs.)
Maximum mass in baggage compartment	: <u>12 kg</u>	(26 lbs.)
Maximum useful load (including fuel)	: see Paragraph 6.6	
Maximum useful load on right seat	: <u>110 kg</u>	(243 lbs.)
Maximum useful load on left seat	: <u>110 kg</u>	(243 lbs.)

MAX TILGARS
min 56.

WARNING

Exceeding the mass limits can lead to overstressing of the airplane and to a degradation of flying characteristics and flight performance.

2.7 CENTER OF GRAVITY

The datum plane for the center of gravity (CG) specifications lies on the leading edge of the wing at the root rib. It is vertical when the fuselage tube lies horizontally. Procedures for a horizontal alignment and empty mass CG specifications can be found in the Maintenance Manual, Section 4.

The permissible flight CG range is:

Maximum forward CG	: 318 mm (12.52 in.) aft of datum plane
Maximum rearward CG	: 430 mm (16.93 in.) aft of datum plane

WARNING

A flight CG which lies outside the permissible range reduces the controllability and stability of the airplane.

The procedure for determining the CG position is included in Section 6.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 12

2.8 APPROVED MANEUVERS

This Powered Sailplane is certified in the Utility category.

CAUTION

Aerobatics and spinning are not permitted.

2.9 MANEUVERING LOAD FACTORS

Table of maximum permissible load factors:

	V_A	V_{NE}
positive	5.30	4.00
negative	-2.65	-1.50

WARNING

Exceeding the maximum permissible load factors may overstress the airplane.

2.10 FLIGHT CREW

Solo flights must be conducted from the left seat.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 13

2.11 KINDS OF OPERATION

The HK 36 TTC is certified for DAY-VFR operation. Night VFR operation, if permitted by the competent authority, requires additional equipment in accordance with national regulations.

IFR, flights in clouds, flights into known icing conditions and aerobatics are not permitted.

2.12 FUEL

Fuel capacity

Standard tank : 55 liters 14.5 US gal.
Long range tank : 79 liters 20.9 US gal. —

Usable fuel

Standard tank : 54 liters 14.3 US gal.
Long range tank : 77 liters 20.3 US gal. —

Approved fuel grades

- Automotive Super, min. octane rating: 95 ROZ, unleaded
- EN 228 Super
- EN 228 Super Plus
- Aviation Grade (AVGAS) 100 LL

91/96 ?

NOTE

Due to its high lead concentration, AVGAS causes increased wear of the valve seats and produces more residue in the combustion chambers. It should therefore only be used at high ambient temperatures (to prevent vapor bubbles) or when other fuel grades are not available.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 14

2.13 AEROTOW, WINCH AND AUTOTOW LAUNCHING

The Powered Sailplane is designed for self-take-off only.

2.14 OTHER LIMITATIONS

Electrical consumers

The landing light and the position lights (optional equipment) may only be used during 10 % of the engine operating time. Otherwise, adequate battery charging cannot be guaranteed.

WARNING

The charging of the battery is of great importance to the prevention of the risk of engine failure, since the engine has no mechanical fuel pump.

Limitations for soaring when using a battery with a capacity of 18 Ah:

The capacity of the lead-accumulator is highly dependent on the temperature. Therefore, the duration of continuous soaring at low temperatures is restricted to:

4 hours at 0° C (32° F),

2 hours at -10° C (14° F).

Good maintenance and charging of the battery are prerequisites. Average current requirement: 0.3 A.

There are no such limitations when a 30 Ah battery is installed.

SE-UDL - 30Ah.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 15

2.15 LIMITATION PLACARDS

The following placard is attached to the left side of the instrument panel:

Maneuvering speed at maximum gross weight	$v_A = 176 \text{ km/h}$
Minimum seat payload, full tank, no baggage	████████
Minimum seat payload, full tank, 12 kg baggage	████████
Maximum permissible useful load	████████

The following optional placard is attached to the instrument panel:

Landing Light and Position Lights
may only be used for
10 % of engine operating time

The following placard is attached to the canopy frame, left side (US registered Serial Nos. only):

This airplane must be operated as a utility category airplane in compliance with the operating limitations as stated in the form of placards, markings, and manuals.

MAXIMUMS:	MANEUVERING SPEED (IAS)	176 km/h (95 kts. / 109 mph)
	GROSS WEIGHT	770 kg (1698 lbs.)
	FLIGHT LOAD FACTOR	+5.3/-2.65


No acrobatic maneuvers, including spin, approved. Altitude loss in a stall recovery: 20 m (65 ft.). Flight into known icing conditions prohibited. This airplane is certified for the following flight operations as of date of original airworthiness certificate: DAY-VFR.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				2 - 16

The following placard is attached to the canopy frame, left side (US and Canadian registered Serial Nos. only):

Altitude		V _{NE} (IAS)		
[m]	[ft.]	[km/h]	[kts.]	[mph]
2000	6500	261	141	162
3000	9800	246	133	153
4000	13100	233	126	145
5000	16400	221	119	137
6000	19600	210	113	130

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997	1	25 Aug 1997		2 - 17



SECTION 3

EMERGENCY PROCEDURES

	Page No.
3.1 INTRODUCTION	3 - 2
3.2 CANOPY JETTISON	3 - 2
3.3 BAILING OUT	3 - 2
3.4 STALL RECOVERY	
3.4.1 Behavior With Power Off	3 - 3
3.4.2 Behavior With Power On	3 - 3
3.4.3 Recovery	3 - 3
3.5 SPIN RECOVERY	3 - 4
3.6 SPIRAL DIVE RECOVERY	3 - 4
3.7 ENGINE FAILURE	
3.7.1 Engine Failure During Take-off	3 - 4
3.7.2 Engine Failure During Cruise	3 - 5
3.7.3 Engine Restart With A Discharged Battery	3 - 6
3.7.4 Propeller Stuck In Feathered Position	3 - 8
3.7.5 Sudden Drop In Manifold Pressure And RPM	3 - 9
3.7.6 Fluctuating Manifold Pressure And RPM	3 - 9
3.7.7 Red Manifold Pressure Warning Light Continuously Illuminated	3 - 10
3.7.8 Red Manifold Pressure Warning Light Flashing	3 - 10
3.7.9 Amber Turbo Caution Light Flashing	3 - 10
3.7.10 Red Fuel Pressure Warning Light Continuously Illuminated	3 - 11
3.7.11 Red Generator Warning Light Continuously Illuminated	3 - 12
3.7.12 Amber Temperature Caution Light Continuously Illuminated	3 - 12
3.7.13 Insufficient Oil Pressure	3 - 13
3.7.14 Excessive Oil Or Cylinder Head Temperature	3 - 13
3.7.15 Excessive RPM	3 - 13
3.7.16 Carburetor Icing	3 - 14
3.8 FIRE	
3.8.1 Fire On Ground	3 - 15
3.8.1 Fire During Take-off	3 - 15
3.8.3 Fire During Flight	3 - 15
3.9 OTHER EMERGENCIES	
3.9.1 Malfunction Or Failure Of The Propeller Speed Control	3 - 16
3.9.2 Icing	3 - 16
3.9.3 Emergency Landing	3 - 16
3.9.4 Emergency Landing On Water	3 - 17

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 1

3.1 INTRODUCTION

Section 3 provides checklists and recommended procedures for use in the case of an emergency.

Since it is impossible to foresee all kinds of emergencies and consider them in the Flight Manual, it is absolutely necessary for the Pilot to know the airplane and to have knowledge and experience in solving problems that may occur. It will only be possible to handle emergency situations safely if the emergency procedures have been practiced.

Emergency procedures relating to optional equipment are given in the corresponding supplements to the Manual.

Any problems which occur must be recorded, along with their remedy, in compliance with the applicable national regulations.

3.2 CANOPY JETTISON

1. Red canopy locks (LH and RH) swing 180° rearward
2. Canopy push up and rearward with both hands

3.3 BAILING OUT

1. Canopy jettison
2. Seat harness release
3. Evacuate airplane

NOTE

When using a manual parachute, wait two seconds after exiting the airplane before pulling the rip-cord.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997	1	25 Aug 1997		3 - 2

3.4 STALL RECOVERY

3.4.1 BEHAVIOR WITH POWER OFF

Under all loading conditions, air brakes extended or retracted, in straight and level or in banked flight, the HK 36 TTC enters a horizontal stall, during which the ailerons remain effective, even with maximum elevator deflection.

A partial loss of positive control in the stick and pedals, buffeting, and a pitch angle of 20° to 30° occur during this condition.

NOTE

During the horizontal stall, the IAS rises to approximately 85 km/h (46 kts. / 53 mph).

3.4.2 BEHAVIOR WITH POWER ON

See behavior with power off. At 50 % to 100 % power, straight and level flight, and maximum rearward center of gravity, the airplane may perform a stall dive over the left or right wing after entering the horizontal stall if the control stick is pulled even further.

NOTE

During a horizontal stall, the airspeed indicator readings fluctuate and are too high.

3.4.3 RECOVERY

The horizontal stall can be terminated immediately by relaxing the force on the elevator control.

NOTE

If the airplane performs a stall dive, immediately relax the force on the elevator control and pull out the airplane smoothly. If the stick is pulled further, the airplane may start to spin.

- * Altitude loss resulting from stationary horizontal stall described above: approximately 10 - 20 m (33 - 65 ft.).
- * Altitude loss resulting from stall dive over a wing: approximately 40 m (130 ft.).

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 3

3.5 SPIN RECOVERY

1. Rudder apply fully opposite to spin direction
2. Control stick forward, ailerons neutral

After spin movement has stopped:

3. Rudder neutral
4. Pull airplane out smoothly

3.6 SPIRAL DIVE RECOVERY

There is no tendency to a spiral dive. The standard recovery procedure is:

1. Rudder apply fully opposite to spiral dive rotation
2. Aileron apply fully opposite to spiral dive rotation
3. Pull airplane out smoothly

3.7 ENGINE FAILURE

3.7.1 ENGINE FAILURE DURING TAKE-OFF

1. Fuel valve check if OPEN
2. Fuel booster pump check if ON
3. Propeller speed control TAKE-OFF
4. Ignition switch BOTH
5. Choke OFF

Carburetor Heat *ON*

1 handed

FFPIC (C)

WARNING

If the symptoms cannot be eliminated immediately and the engine refuses to deliver enough power, a straight-in landing must be performed if below 80 m (260 ft.) AGL.

Before touchdown:

- Fuel valve CLOSED
- Ignition OFF
- Master switch OFF

100 m ?

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 4

3.7.2 ENGINE FAILURE DURING CRUISE

1. Fuel valve check if OPEN
2. Fuel booster pump ON
3. Choke check if OFF
4. Carburetor heat ON at power settings below 75 %

NOTE

When the carburetor heat is activated at a high power setting, the maximum admissible airbox temperature can be exceeded, resulting in increased engine wear.

5. Ignition check if switch is in "BOTH" position
6. Fuel quantity check

NOTE

If the symptoms cannot be eliminated and the engine refuses to deliver enough power, proceed as follows:

1. Throttle control IDLE
2. Ignition OFF
3. Propeller feather
4. Fuel valve CLOSED
5. Master switch OFF
- ✗ 6. Airspeed best glide speed
(105 km/h (57 kts. / 65 mph))
- ✗ 7. Look for a suitable landing field
- ✗ 8. Cowl flap CLOSE

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 5

3.7.3 ENGINE RESTART WITH A DISCHARGED BATTERY (during flight)

1. Electrical consumers OFF
2. Fuel valve OPEN
3. Master switch ON
4. Mode select switch POWER FLIGHT
5. Choke as required
6. Throttle control IDLE
7. Ignition switch BOTH
8. Airspeed increase to between 180 and 200 km/h
(97 - 108 kts. / 112 - 124 mph)
9. Propeller speed control very slowly move from FEATHER to TAKE-OFF
10. Oil pressure should be available within 10 seconds
11. Choke re-adjust if required
12. Propeller check:
 - Throttle control adjust to 2000 RPM
 - Propeller speed control CRUISE (pull back to cam before FEATHER position),
wait until speed drops to approximately 1900 RPM;
reset to TAKE-OFF position

Repeat procedure at least three times.

CAUTION

Without repeating this procedure, it is not ensured that the pitch change mechanism will operate faultlessly.

13. RPM and throttle as required to continue flight

CAUTION

After prolonged soaring periods, adequate altitude reserve must be ensured for engine warm-up.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 6

14. All electrical consumers
essential for flight operation ON

WARNING

When the battery charge state is already very poor, it is not possible to recharge it. However, the electric main fuel pump is supplied with power by the generator via the on board electrical network.

CRS!

15. Ammeter check if battery is being charged
(indicator clearly in positive range)

WARNING

If the battery is not being charged, land on next airfield and correct the fault. Without a serviceable battery, a generator failure will lead to engine failure.

16. Continue flight normally
17. Determine reason for battery discharge

CAUTION

The engine is started due to windmilling. Because of the high airspeed required for this process, an altitude loss of up to 300 m (1000 ft.) must be expected. The maximum admissible airspeeds must not be exceeded.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 7

3.7.4 PROPELLER STUCK IN FEATHERED POSITION

NOTE

The propeller requires hydraulic pressure for pitch reduction. The hydraulic pressure is supplied through a pressure accumulator. When this accumulator is empty, the pressure must be built up by the oil pump of the engine. The engine is started with the propeller in feathered pitch and the throttle control in IDLE position.

1. Electrical consumers OFF
2. Fuel valve OPEN
3. Master switch ON
4. Mode select switch POWER FLIGHT
5. Fuel booster pump ON
Check whether the red warning light extinguishes after build-up of fuel pressure.
6. Choke as required
7. Throttle control IDLE
8. Ignition switch BOTH
9. Propeller speed control TAKE-OFF
10. Ignition switch turn clockwise to start engine until the propeller adopts the working position

CAUTION

It is possible to start the engine with the propeller in the feathered position, although this significantly increases engine wear.

11. Oil pressure should be available within 10 seconds
12. Choke re-adjust as required
13. RPM and throttle as required to continue flight
14. Fuel booster pump OFF
15. Electrical consumers ON
16. Continue flight normally
17. After landing, determine the reason for the loss of oil pressure and correct the fault.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 8

3.7.5 SUDDEN DROP IN MANIFOLD PRESSURE AND RPM

In case of loud noise or bang: it is very likely that the turbocharger is damaged.

1. Proceed to next airfield, keep watching oil pressure
2. Throttle control keep manifold pressure in admissible range
3. Propeller speed control keep RPM in admissible range

NOTE

If the symptoms cannot be eliminated and the engine refuses to deliver enough power, proceed as follows:

1. Throttle control IDLE
2. Ignition OFF
3. Propeller feather
4. Fuel valve CLOSED
5. Master switch OFF
6. Airspeed best glide speed
(105 km/h (57 kts. / 65 mph))
7. Look for a suitable landing field
8. Cowl flap CLOSE

3.7.6 FLUCTUATING MANIFOLD PRESSURE AND RPM

1. TCU OFF
2. Propeller speed control make slight RPM changes in order to bleed system
3. TCU ON

If manifold pressure and RPM do not stabilize:

1. TCU OFF
2. Throttle control keep manifold pressure in admissible range
3. Propeller speed control keep RPM in admissible range
4. Land on nearest airfield and determine reason for malfunction

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 9

3.7.7 RED MANIFOLD PRESSURE WARNING LIGHT CONTINUOUSLY ILLUMINATED

The manifold pressure limit has been exceeded.

1. Throttle control keep manifold pressure in admissible range
2. Propeller speed control keep RPM in admissible range
3. Land on nearest airfield and determine reason for malfunction

3.7.8 RED MANIFOLD PRESSURE WARNING LIGHT FLASHING

The time limit for engine take-off power has been exceeded.

1. Throttle control keep manifold pressure in admissible range
2. Propeller speed control keep RPM in admissible range
3. Continue flight normally

3.7.9 AMBER TURBO CAUTION LIGHT FLASHING

Defect in the area of the sensors, sensor wiring, or Turbo Control Unit or leakage of the airbox.

1. Throttle control keep manifold pressure in admissible range
2. Propeller speed control keep RPM in admissible range

CAUTION

If it is impossible to control RPM and manifold pressure manually:

Turbo Control Unit OFF

3. Land on nearest airfield and determine reason for malfunction

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 10

3.7.10 RED FUEL PRESSURE WARNING LIGHT CONTINUOUSLY ILLUMINATED

Fuel pressure has dropped below the minimum.

1. Fuel booster pump ON
2. Fuel valve check if OPEN
3. Fuel quantity indicator check fuel quantity
4. Ammeter check if in positive range, otherwise switch OFF all equipment that is not needed

If light extinguishes

Land on nearest airfield and determine reason for malfunction.

WARNING

The main fuel pump is supplied with power by the generator. A generator failure will lead to the failure of the main fuel pump, causing the warning light to come on. Therefore, the illumination of the fuel pressure warning light can be an indication of generator failure. In this case, the on board network, including the fuel booster pump, is supplied with power only from the battery. All electrical consumers which are not essential to flight operation must be switched OFF. The load on the battery must be monitored by means of the ammeter which should not be too far in the negative range. The current requirement with all switchable consumers switched OFF is approximately 6 A. With a charged, well maintained battery, the fuel booster pump will be supplied with power for another 30 minutes.

Vill light vid m. H. p. m. 1

If light does not extinguish

The required fuel flow cannot be maintained, or the fuel pressure switch is defective. However, an engine failure is possible at any time. See NOTES in Article 3.7.2 ENGINE FAILURE DURING CRUISE.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 11

3.7.11 RED GENERATOR WARNING LIGHT CONTINUOUSLY ILLUMINATED

The generator is not delivering power to the on board network.

1. Fuel booster pump ON
2. All electrical consumers not essential for flight operation OFF
3. Land on nearest airfield and determine reason for malfunction

WARNING

The engine has no mechanical fuel pump. In case of generator failure, the fuel booster pump is supplied with power from the battery. The remaining flight duration with the engine running depends on the charge state of the battery. With a charged, well maintained battery, the remaining flight duration is approximately 30 minutes with the electrical consumers switched OFF.

3.7.12 AMBER TEMPERATURE CAUTION LIGHT CONTINUOUSLY ILLUMINATED

The admissible exhaust gas temperature (EGT) or the admissible airbox temperature has been exceeded. Excessive EGT will cause damage to the exhaust system. Excessive airbox temperatures lead to increased engine wear.

1. Carburetor heat OFF
2. Throttle control reduce power as soon as the situation allows so that caution light extinguishes

NOTE

When the carburetor heat is on, the airbox temperature will increase. At a power setting above 75 %, the use of carburetor heat is unnecessary and not recommended, as the maximum admissible airbox temperature can be exceeded.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 12

3.7.13 INSUFFICIENT OIL PRESSURE

1. Throttle control reduce manifold pressure as far as the situation allows
2. Land on nearest airfield and determine reason for insufficient oil pressure

WARNING

Engine failure can occur at any time.

3.7.14 EXCESSIVE OIL OR CYLINDER HEAD TEMPERATURE

1. Cowl flap check if OPEN
2. Throttle control reduce manifold pressure as far as the situation allows
3. Propeller speed control reduce RPM as far as the situation allows
4. Land on nearest airfield and determine reason for high temperature

WARNING

Engine failure can occur at any time.

3.7.15 EXCESSIVE RPM

1. Propeller speed control reduce RPM as far as the situation allows
2. Throttle control reduce manifold pressure as far as the situation allows
3. Land on nearest airfield and determine reason for high temperature

WARNING

Engine failure can occur at any time.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 13

3.7.16 CARBURETOR ICING**NOTE**

Carburetor icing can be recognized by a drop in the engine RPM and/or loss of manifold pressure and/or irregular running of the engine without a change in the throttle control position, the choke position, the propeller setting, the airspeed, or the altitude.

CAUTION

Since the turbocharger increases the effect of intake air heating, the activation of the carburetor heat is not recommended at power settings above 75 %.

1. Carburetor heat ON at power settings below 75 %

NOTE

The engine output will slightly drop, due to the intake air heating, and fuel consumption will slightly increase.

2. Carburetor heat OFF as required

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 14

3.8 FIRE

3.8.1 FIRE ON GROUND

1. Fuel valve CLOSED
2. Throttle control FULL
3. Master switch OFF
4. Cabin air CLOSE
5. Cabin heat OFF

3.8.2 FIRE DURING TAKE-OFF

1. Master switch OFF
2. Cabin air CLOSE
3. Cabin heat OFF

After reaching a safe altitude:

4. Fuel valve CLOSE
5. Engine shut down
6. Perform landing with engine off (see Section 4)

3.8.3 FIRE DURING FLIGHT

1. Fuel valve CLOSE
2. Throttle control FULL
3. Master switch OFF
4. Cabin air CLOSE
5. Cabin heat OFF
6. Engine shut down
7. Perform landing with engine off (see Section 4)

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 15

3.9 OTHER EMERGENCIES

3.9.1 MALFUNCTION OR FAILURE OF PROPELLER SPEED CONTROL

1. Throttle control keep RPM in admissible range
2. Airspeed reduce

3.9.2 ICING

1. Leave icing area
2. Constantly move the controls to prevent them from becoming locked by ice
3. If the canopy is iced over:
weather window open
cabin heat ON

3.9.3 EMERGENCY LANDING

1. Engine shut down
2. Perform landing with power off (see Section 4)

WARNING

Ensure that landing area is clear of obstacles. Touch-down with lowest possible airspeed and apply brakes carefully.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 16

3.9.4 EMERGENCY LANDING ON WATER

Emergency landings on water should be performed only in extreme emergency situations, since it must be assumed, from trials with sailplanes, that the airplane will submerge immediately after touching the water and then surface again.

1. Parachute harness open
2. Seat harness tighten
3. Airspeed normal approach speed
4. Touchdown with minimum speed and air brakes retracted

NOTE


Conditions such as strong headwind, danger of wind shear, turbulence, or wet wings require a higher approach speed.

WARNING

On touchdown, protect your face with one arm!

5. Seat harness release
6. Red canopy locks (LH and RH) swing 180° rearward
7. Canopy push up and away
8. Evacuate airplane as quickly as possible

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				3 - 17



SECTION 4

NORMAL PROCEDURES

	Page No.
4.1 INTRODUCTION	4 - 2
4.2 RIGGING AND DE-RIGGING	
4.2.1 General	4 - 2
4.2.2 Wing Installation (Folding Mechanism Not Provided)	4 - 3
4.2.3 Wing Installation (Folding Mechanism Provided)	4 - 4
4.2.4 Wing Removal	4 - 5
4.2.5 Winglet Installation	4 - 5
4.2.6 Winglet Removal	4 - 5
4.2.7 Horizontal Stabilizer Installation	4 - 6
4.2.8 Horizontal Stabilizer Removal	4 - 6
4.3 DAILY INSPECTION	4 - 7
4.4 PREFLIGHT INSPECTION	4 - 13
4.5 NORMAL PROCEDURES AND RECOMMENDED SPEEDS	
4.5.1 Launch/Engine Starting, Run Up & Taxiing Procedures	4 - 13
4.5.2 Take-Off And Climb	4 - 16
4.5.3 Flight (Including In-Flight Engine Stop/Start Procedures)	4 - 18
4.5.4 Approach	4 - 21
4.5.5 Landing	4 - 21
4.5.6 (Omitted)	
4.5.7 High Altitude Flight	4 - 25
4.5.8 Flight In Rain	4 - 26
4.5.9 Aerobatics	4 - 26
4.5.10 Engine Shut-down	4 - 26
4.5.11 Parking	4 - 27

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 1

4.1 INTRODUCTION

Section 4 contains checklists and a description of the normal operating procedures which is based on the results of flight tests. Normal procedures associated with optional systems can be found in Section 9. The refilling of operating fluids must be recorded in compliance with national regulations.

4.2 RIGGING AND DE-RIGGING

4.2.1 GENERAL

Each wing is connected to the fuselage by three bolts. The two main bolts are located at the center of the spar tunnel. They are accessible between the backrests and can be inserted from the front side. A spring loaded hook is placed over the bolt handles to secure the bolts.

The A- and B-bolts are fixed to the fuselage at the wing root. The A-bolt is placed in front of the spar tunnel and the B-bolt lies near the trailing edge. Self locking units are screwed onto the B-bolts, which are accessible through handholes on the upper surface of the wing. Locking rings are integrated in the B-bolt locking units, which therefore do not require any further safetying.

The horizontal stabilizer is attached to the vertical stabilizer by means of three bolts. The two bolts at the rear are fixed to the mount in the vertical stabilizer. The threaded bolt located at the front is fitted with a hexagonal socket. When screwed in, it is automatically secured by means of a locking ring integrated into the horizontal stabilizer.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 2

4.2.2 WING INSTALLATION (WING FOLDING MECHANISM NOT PROVIDED)

1. Clean all bolts and bushes and the B-bolt locking unit and apply a light coat of grease.
2. Lift one wing (two persons at the root rib, one at the wing tip) and insert spar stump into spar tunnel. Ensure the smooth insertion of the A- and B-bolts. Connect position and strobe lights (optional) when the gap between fuselage and wing is just wide enough to reach the wires.
3. Insert main bolt while moving the wing tip in small circles. The aileron and air brake control systems are automatically connected. Do not release the wing before the main bolt has been completely inserted.
The wide track of the landing gear allows the attached wing to support itself; no outside support is required.
4. Screw the B-bolt locking unit onto the B-bolt and tighten it by hand.
5. Install the other wing in a similar manner.
6. Tighten both B-bolt locking units with a wrench (size 17 mm), applying moderate hand torque (approximately 6 Nm (4.5 ft.lbs.)).
7. Secure main bolts with spring loaded hook.
8. Apply water resistant adhesive tape to the gap between fuselage and wing.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997	1	25 Aug 1997		4 - 3

4.2.3 WING INSTALLATION (WING FOLDING MECHANISM PROVIDED)

1. Clean all bolts, bushes and the B-bolt locking unit and apply a light coat of grease, remove lid over B-bolt handhole.
2. Unhook one wing from its hanging mount and pull it rearward to the stop. A second person should stand between the wing and fuselage and relieve the load on the telescopic tube by lifting the wing at the spar stump.
3. Walk forward until the wing is 90° from line of flight; rotate the wing until the root ribs are parallel; keep wing in its correct position.
4. Introduce spar stump into spar tunnel while ensuring the smooth insertion of A- and B-bolts. Connect position and strobe lights (optional) when the gap between the fuselage and wing is just wide enough to reach the wires.
5. Insert main bolt. The aileron and air brake control systems are automatically connected. Do not release the wing before the main bolt has been completely inserted. The wide track of the landing gear allows the attached wing to support itself; no outside support is required.
6. Screw the B-bolt locking unit onto the B-bolt and tighten it by hand.
7. Install the other wing in a similar manner.
8. Tighten both B-bolt locking units with a wrench (size 17 mm), applying moderate hand torque (approximately 6 Nm (4.5 ft.lbs.)).
9. Secure main bolts with the spring loaded hook.
10. Apply water resistant adhesive tape to the gap between fuselage and wing.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997	1	25 Aug 1997		4 - 4

4.2.4 WING REMOVAL

To remove the wings, reverse the procedure.

NOTE

When installing or removing the wings, prevent the airplane from falling onto its nosewheel or tail skid due to the CG movement.

4.2.5 WINGLET INSTALLATION

1. Clean the bolts and bushes if necessary.

CAUTION

Do not lubricate the bolt threads!

2. Install winglet with washers and self locking nuts.
3. Tighten self locking nuts with moderate hand torque (approximately 6 Nm (4.5 ft.lbs.)).
4. Apply water resistant adhesive tape to the gap.

4.2.6 WINGLET REMOVAL

To remove the winglet, reverse the procedure.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 5

4.2.7 HORIZONTAL STABILIZER INSTALLATION

1. Clean all bushes and bolts and apply a light coat of grease.
2. Move the trim knob to full NOSE DOWN position.
3. Remove the Pitot tube.
4. Position the horizontal stabilizer over the stabilizer mount; the elevator control rod **must be connected by a second person.**

WARNING

The elevator control system is not connected automatically!

5. Slip the horizontal stabilizer onto both rearward bolts.
6. Screw in the fastening bolt to the stop with an 8 mm hexagon key, applying moderate hand torque (approximately 6 Nm (4.5 ft.lbs.)).
7. Check the horizontal stabilizer for insecure attachment and inspect load transmission of elevator control system.
8. Install the Pitot tube.
9. Apply water resistant adhesive tape to the gap between the horizontal stabilizer and the vertical stabilizer.

4.2.8 HORIZONTAL STABILIZER REMOVAL

To remove the horizontal stabilizer, reverse the procedure.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 6

4.3 DAILY INSPECTION

WARNING

Master switch OFF, ignition OFF!

1. Fuel tank drain check: drain off about 1/8 liter (approximately 1/8 US quart) of fuel using a transparent drain cup (see Paragraph 7.10). Inspect for dirt or water.

NOTE

In order to prevent the water deposited in the tank from dispersing, the airplane should not be agitated prior to the drain check.

2. Ensure completeness of the onboard documents and ensure that the remaining operating time before the next scheduled inspection (100, 200 or 600 hrs.) allows for the intended flight.
3. Inspect left fuselage skin for damage or cracks.
4. Inspection of vertical stabilizer:
 - Check skin for damage or cracks.
 - Check rudder for improper or insecure mounting.
 - Check for excessive play.
 - Check rudder control system for improper connection and interference.
 - Remove Pitot tube cover.
 - Check Pitot tube for improper mounting and blockage of bores.
5. Inspection of horizontal stabilizer:
 - Check horizontal stabilizer and tips for improper mounting and insecure attachment and inspect skin for damage and cracks.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 7

- Check elevator for improper mounting, play, damage and cracks.
 - Check elevator control system for improper connection, lack of load transmission and interference.
6. Inspect right fuselage skin for damage and cracks.
7. Inspection of right wing:
- Check wing, aileron and winglet for improper or insecure mounting, excessive play, damage, and cracks.
 - Check aileron control system for improper connection, lack of load transmission and interference.
 - Check air brakes for incomplete retraction; ensure flushness with the wing surface.
 - Check air brake control system for improper connection, lack of load transmission and interference.
 - Check air brake box for foreign bodies.
8. Inspection of right main landing gear:
- Check landing gear strut for damage and cracks.
 - Check wheel fairing for damage and looseness.
 - Visually check tires and brakes.
 - Ensure correct inflation (2.3 bar (33 psi)).
9. Inspection of propeller:
- Check propeller blades for damage, cracks and excessive play.
 - Check spinner for damage and insecure mounting.
10. Inspection of nose landing gear:
- Check nosewheel strut for damage and cracks.
 - Check wheel fairing for damage and looseness.
 - Visually check tire.
 - Ensure correct inflation (1.8 bar (26 psi)).

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 8

11. Oil and coolant check:

- Check oil level.

NOTE

The oil consumption is minor, but becomes somewhat greater with a full oil tank. Therefore, only refill engine oil when the oil level reaches or falls below the minimum marking.

- Ensure coolant level in equalizing reservoir is more than 1/3.

NOTE

The coolant equalizing reservoir should not be more than 2/3 full.

- Check engine compartment for obvious defects.
- Check coolers for obstruction.
- Check air intake opening for foreign bodies.

12. Inspection of left main landing gear:

- Check landing gear strut for damage and cracks.
- Check wheel fairing for damage and looseness.
- Visually check tires and brakes.
- Ensure correct inflation (2.3 bar (33 psi)).

13. Inspection of left wing:

- Check wing, aileron and winglet for improper or insecure mounting, excessive play, damage, and cracks.
- Check aileron control system for improper connection, lack of load transmission, and interference.
- Check air brakes for incomplete retraction; ensure flushness with the wing surface.
- Check air brake control system for improper connection, lack of load transmission and interference.
- Check air brake box for foreign bodies.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 9

14. Check in the cabin:

- Check if loading is admissible (refer to Section 6).

NOTE

Ensure compliance with loading restrictions by changing and/or rearranging the useful load.

- Master switch ON
- Mode select switch POWER FLIGHT
- All circuit breakers pushed in
- Fuel quantity check using fuel quantity indicator and log book entries; refuel if necessary

NOTE

Usable fuel quantity and approved fuel grades: see Paragraph 2.12, FUEL.

- Master switch OFF
- Cabin check for foreign bodies and loose objects
- Canopy check for dirt and damage
- Cowl flap check for improper operation
- Main bolts verify that bolts are properly secured

15. Check of propeller FEATHER position:

- Rudder pedals adjust
- Canopy closed & locked
- Fuel valve OPEN
- Parking brake set
- Electrical consumers OFF
- Master switch ON
- Mode select switch POWER FLIGHT

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 10

- Propeller speed control TAKE-OFF
- Cowl flap OPEN
- Fuel booster pump ON; verify red warning light extinguishes after build up of fuel pressure
- Throttle control IDLE
- Choke ON if engine is cold

WARNING

People must stay clear of the propeller danger zone!

- Ignition switch turn clockwise to start engine
- Throttle control adjust to approximately 1000 RPM
- Oil pressure must reach green range within 10 seconds

CAUTION

If oil pressure is too low, turn off engine immediately!

NOTE

When the Powered Sailplane has been parked for long periods, or the hydraulic pressure accumulator is emptied for any other reason, a loss of oil pressure may occur after oil pressure build up in the area of the oil pressure sensor. The reason for this is the filling process of the accumulator. The oil pressure indicator may drop to zero for a maximum of 15 seconds.

- Choke push forward as required
- Fuel booster pump OFF
- At increased idle speed (approximately 1000 RPM), turn off ignition and simultaneously pull propeller speed control all the way back to the FEATHER position.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 11

NOTE

Unless the propeller speed control is actuated simultaneously with the ignition switch, the propeller will remain in the take-off position. Propeller feathering is only possible at 800 RPM or above (see Article 7.9.5, PROPELLER SPEED CONTROL).

- Propeller speed control TAKE-OFF

NOTE

If the propeller does not move to the take-off position, apply the emergency procedure described in Paragraph 3.7, ENGINE FAILURE.

- Master switch OFF
- Mode select switch SOARING

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 12

4.4 PREFLIGHT INSPECTION

The following checklist with the most important items is located where it is well visible for both Pilots:

START CHECK
1. Mass & Balance checked
2. Main bolts secured
3. Fuel valve OPEN
4. Fuel quantity checked
5. Canopy locked
6. Seat harness on and secure
7. Propeller check
8. Magneto check
9. Carburetor heat OFF
10. Controls free
11. Trim checked
12. Parking brake released
13. Air brakes locked
14. TCU ON
15. Fuel booster pump ON

4.5 NORMAL PROCEDURES AND RECOMMENDED SPEEDS

4.5.1 LAUNCH/ENGINE STARTING, RUN UP & TAXIING PROCEDURES

1. Rudder pedals adjust
2. Seat harnesses fasten
3. Canopy closed & locked
4. Fuel valve OPEN
5. Controls free
6. Air brakes verify proper operation
7. Air brakes lock
8. Parking brake set
9. Electrical consumers OFF
10. Master switch ON
11. Mode select switch POWER FLIGHT

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 13

12. Warning and caution lights All warning and caution lights light up; some extinguish automatically after approximately 2 seconds.
13. Propeller speed control TAKE-OFF
14. Fuel quantity indicator check
15. Cowl flap OPEN
16. Fuel booster pump ON; verify red warning light extinguishes after build up of fuel pressure
17. Throttle control IDLE
18. Choke ON if engine is cold

WARNING

People must stay clear of the propeller danger zone!

19. Ignition switch turn clockwise to start engine
20. Throttle control adjust to approximately 1000 RPM
21. Oil pressure must reach green range within 10 seconds

CAUTION

If the oil pressure is too low, turn off engine immediately!

NOTE

When the Powered Sailplane has been parked for long periods, or the hydraulic pressure accumulator is emptied for any other reason, a loss of oil pressure may occur after oil pressure build up in the area of the oil pressure sensor. The reason for this is the filling process of the accumulator. The oil pressure indicator may drop to zero for a maximum of 15 seconds.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 14

22. Choke push forward as required

WARNING

If the engine is warm, the activated choke will considerably reduce the engine output!

23. Fuel booster pump OFF
24. Fuel pressure warning light verify main fuel pump maintains fuel pressure
25. Electrical consumers ON or OFF as required
26. Altimeter set
27. Oil temperature check

CAUTION

Before loading the engine, allow the oil temperature to rise to 50° C (122° F) with the cowl flap open at 1000 to 1500 RPM (also possible during taxiing).

28. Choke OFF
29. Ignition circuits check:
- Throttle control adjust to 1600 RPM
 - Ignition circuits check; drop should be 50 to 150 RPM;
difference between circuits 1 and 2 should not exceed 50 RPM.

CAUTION

If RPM drop is too high at low outside temperatures, repeat check with the carburetor heat ON.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 15

30. Carburetor heat check at 1600 RPM;
drop should be approximately 20 RPM
31. Propeller check:
- Throttle control adjust to 2000 RPM
 - Propeller speed control CRUISE (carefully pull back to cam before FEATHER position)
wait until speed drops to approximately 1900 RPM
reset to TAKE-OFF position

Repeat procedure at least three times.

CAUTION

Without repeating the procedure, it is not ensured that the pitch change mechanism will operate faultlessly.

32. Power plant instruments verify all indicators are in admissible range

4.5.2 TAKE-OFF AND CLIMB

1. Cowl flap OPEN
2. Fuel booster pump ON
3. Propeller speed control TAKE-OFF
4. Throttle FULL (2350 ± 35 RPM, manifold pressure in yellow range)

CAUTION

The manifold pressure for take-off power is set with the throttle control in the foremost 1/2 cm (1/5 in.) of the setting range. The TCU sets the take-off manifold pressure. In this range, it is not possible to control the manifold pressure with the throttle control. With high outside air temperatures at high field elevations, the highest permitted manifold pressure will not be reached.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 16

5. Start take-off run with elevator neutral, maintaining direction with rudder.
6. Lift nosewheel at approximately 80 km/h (43 kts. / 50 mph); airplane will lift off by itself at approximately 90 km/h (49 kts. / 56 mph).
Rotation
7. Perform climb with at least 97 km/h (52 kts. / 60 mph); monitor oil pressure, oil temperature and cylinder head temperature, which must all stay within the green range.
8. At a height of 100 m (330 ft.) AGL:
 - Fuel booster pump OFF

If the fuel system is intact, the red warning light must not illuminate, since the main fuel pump maintains the fuel pressure.

9. After reaching a safe altitude:
 - Propeller speed control set RPM below yellow range
 - Throttle control set manifold pressure below yellow range

For best angle of climb, adjust airspeed to 97 km/h (52 kts. / 60 mph). For best rate of climb, adjust to 110 km/h (59 kts. / 68 mph). Figures apply to maximum T/O mass (max. gross weight).

CAUTION

The manifold pressure for maximum continuous power is set in the range from 1/2 to 1 1/2 cm (1/5 to 3/5 in.) behind the foremost throttle control position. In this range, the TCU sets the manifold pressure between 32 and 34 inHg and it is not possible to control the manifold pressure with the throttle control.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 17

4.5.3 FLIGHT (INCLUDING IN-FLIGHT ENGINE STOP/START PROCEDURES)**NOTE**

Economic power settings can be found in Article 5.3.7.

WARNING

When setting the power in turbulent air, make sure not to exceed

V_{RA} .

In-flight engine stop

1. Throttle control IDLE

CAUTION

In order to avoid overheating the bearings in the turbocharger, the engine must be cooled down at a low power setting for approximately one minute before being turned off.

2. Electrical consumers OFF

WARNING

Engine start can become impossible:

- After prolonged soaring with several electrical consumers switched on (mis-operation of mode select switch)
- In extreme cold (see Paragraph 2.14, OTHER LIMITATIONS)
- If the battery is in a poorly maintained condition or barely charged

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 18

- Airspeed maintain approximately 100 km/h (54 kts. / 62 mph).

NOTE

At airspeeds below 100 km/h (54 kts. / 62 mph), the windmilling propeller RPM becomes very low or the propeller stops. However, the propeller will only feather at a sufficient RPM (above 800).

- Ignition OFF
- Propeller speed control FEATHER (pull all the way back over the cam)

NOTE

The propeller rotates after ignition shut-off due to windmilling. Feathering will occur with the propeller rotating.

- Mode select switch SOARING
- Cowl flap CLOSE

In-flight engine start

- Electrical consumers OFF
- Master switch ON
- Mode select switch POWER FLIGHT
- Propeller speed control TAKE-OFF
- Cowl flap OPEN
- Choke ON if engine is cold
- Fuel booster pump ON
- Throttle control IDLE
- Ignition switch turn clockwise to start engine
- Oil pressure check

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 19

NOTE

The hydraulic pressure accumulator is not full after the propeller pitch change. After pressure build-up, there might be a loss of oil pressure in the area of the oil pressure sensor. The reason for this is the filling process of the pressure accumulator. The oil pressure indicator may drop to zero for a maximum of 15 seconds.

11. Choke OFF if necessary
12. Fuel booster pump OFF
13. Fuel pressure warning light verify main fuel pump maintains fuel pressure
14. Electrical consumers ON as required
15. Oil temperature check
16. Propeller check:
 - Throttle control adjust to 2000 RPM
 - Propeller speed control CRUISE (carefully pull back to cam before FEATHER position)
wait until speed drops to approximately 1900 RPM
reset to TAKE-OFF position

Repeat procedure at least three times.

CAUTION

Without repeating the procedure, it is not ensured that the pitch change mechanism will operate faultlessly. The propeller system becomes bled by this procedure. If this check is not carried out, the propeller pitch could fluctuate.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 20

Sideslips

The speed range in which sideslips can be performed depends on the strength of the Pilot, since significant rudder control forces are required at higher airspeeds. Usually, the upper limit is approximately 150 km/h (81 kts. / 93 mph).

A control force reversal can occur when the rudder is fully deflected and the ailerons are deflected opposite to the rudder. To recover, either release the aileron control or apply approximately 30 N (7 lbs.) to the rudder pedal to overcome the control force reversal.

4.5.4 APPROACH

1. Throttle control reduce power as required

WARNING

When setting the power in turbulent air, make sure not to exceed

V_{RA}

2. Carburetor heat ON if required
3. Trim adjust as required
4. Air brakes apply as required

4.5.5 LANDING

Power-on landing

1. Propeller speed control TAKE-OFF
2. Fuel booster pump ON
3. Throttle control reduce power
4. Carburetor heat ON
5. Cowl flap OPEN
6. Trim adjust as required
7. Air brakes apply as required

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 21

NOTE

The air brake lever locks when the air brakes are extended half way. With slightly increased force, this position can be overtraveled in either direction. With the air brakes locked in the half extended position, it is possible to control the glide path with the throttle control. The maximum airspeed for air brakes fixed in the half extended position (v_{ABF}) must not be exceeded.

8. Sideslip possible, but not necessary
9. Approach speed 105 km/h (57 kts. / 65 mph) during final approach

NOTE

Conditions such as strong headwind, danger of wind shear, turbulence, or wet wings require a higher approach speed.

10. Touchdown on main landing gear
11. Wheel brakes apply as required, using toe brakes

CAUTION

The wheels have a differential braking system. Apply toe brakes symmetrically to avoid skidding.

12. Fuel booster pump OFF

Balked landing with the engine running

1. Air brakes retract
2. Carburetor heat OFF
3. Throttle control FULL

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 22

WARNING

When approaching with the air brakes fixed in the half extended position, one hand on the control stick and the other on the throttle control, FIRST select full throttle, then retract the air brakes.

NOTE

Climbing is possible with the air brakes fixed in the half extended position.

4. Perform climb with at least 97 km/h (52 kts. / 60 mph). Monitor oil pressure, oil temperature, and cylinder head temperature which must all stay within the green range.
5. At a height of approximately 100 m (330 ft.) AGL:
 - Fuel booster pump OFF

If the fuel system is intact, the red warning light must not illuminate, since the main fuel pump maintains the fuel pressure.

Power-off landing

NOTE

If the propeller is feathered, sufficient height must be allowed on approach to ensure that the landing field is reached, since starting the engine takes too much time during final approach!

1. Trim adjust as required
2. Air brakes apply as required

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 23

NOTE

The air brake lever locks when the air brakes are extended half way. With slightly increased force, this position can be overtraveled in either direction.

3. Approach speed 105 km/h (57 kts. / 65 mph) during final approach

NOTE

Conditions such as strong headwind, danger of wind shear, turbulence, or wet wings require a higher approach speed.

4. Touchdown on main landing gear
5. Wheel brakes apply as required, using toe brakes

CAUTION

The wheels have a differential braking system. Apply toe brakes symmetrically to avoid skidding.

4.5.6 (omitted)

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 24

4.5.7 HIGH ALTITUDE FLIGHT

The never exceed speed is reduced at pressure altitudes above 2000 meters (6500 ft.), as shown in the following table.

Pressure altitude		Never exceed speed (V _{NE})		
meters	feet	km/h	kts.	mph
0 to 2000	0 to 6500	261	141	162
2000 to 3000	6500 to 9800	246	133	153
3000 to 4000	9800 to 13100	233	126	145
4000 to 5000	13100 to 16400	221	119	137
5000 to 6000	16400 to 19600	210	113	130

WARNING

Due to the lack of oxygen at high altitudes, perception and reaction become greatly reduced and even unconsciousness may occur. The use of oxygen apparatus is strongly advised for flights above 3500 m (11500 ft.). National legislation for flights at high altitudes should be referred to.

WARNING

During the flight tests, the Powered Sailplane was only tested up to altitudes of 5000 m (16000 ft.).

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997	1	25 Aug 1997		4 - 25

4.5.8 FLIGHT IN RAIN**NOTE**

Flight performance deteriorates in rain. The impact on the flying characteristics is minor. Flight in very heavy rain should be avoided because of the reduced visibility.

4.5.9 AEROBATICS**NOTE**

Aerobatics and spinning are not permitted.

4.5.10 ENGINE SHUT-DOWN

1. Propeller speed control TAKE-OFF
2. Throttle IDLE

CAUTION

In order to avoid overheating the turbocharger bearings, the engine must be cooled down at a low power setting for approximately one minute before being turned off. This should be observed especially after engine test running. Sufficient cooling usually occurs through landing approach and subsequent taxiing.

3. Parking brake set (see Paragraph 7.5)
4. Fuel booster pump OFF
5. Electrical consumers OFF
6. Ignition OFF
7. Master switch OFF

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 26

8. Mode select switch SOARING
9. Air brakes lock

4.5.11 PARKING

When parking for a short time, the airplane should be oriented in headwind direction with the parking brake set and the air brakes fixed in the half extended position. In case of longer unattended parking or in unpredictable wind conditions, the airplane should be moored or stored in a hangar. It is also advisable to cover the Pitot tube.

CAUTION

Avoid outdoor parking for prolonged periods of time.

NOTE

The Powered Sailplane should not be parked with the propeller in the feathered pitch position. With an empty oil pressure accumulator, the propeller cannot assume the take-off position. Starting the engine with the propeller in feathered pitch is possible, but significantly increases engine wear.

Doc. No.	Issue	Rev. No.	Date	Source	Page No.
3.01.20-E	03 Mar 1997				4 - 27

